



## FluidInspectIR<sup>®</sup>

### MIRS-T-V



## Product Description

The MIRS8-T-V transmission sensor is a rugged and robust sensor designed for online measurements of oils in moving vehicles.

The MIRS8-T-V is a novel sensor platform targeted to be used in mobile machinery, agricultural equipment, construction machinery or military vehicles.

The sensor complies with the demanding EMV and vibration specification for these applications.

The oil sample is provided to the sensor via compression fitting (6mm) and the sensor typically determines relevant oil parameters such as oxidation, water, soot, TAN, TBN and additive concentrations.

The exact parameters that can be measured are dependent on the oil type used and the sensor will be specifically calibrated for each oil type.

The sensor should be mounted directly after an oil filter to ensure that no particles >50µm are entering the sensor.

## Summary Information

- Mid-infrared sensor for oil analysis in moving vehicles
- Used in mobile machinery, agricultural equipment, military
- 8 customised payload channels
- Vibration and shock tested to Standard AECTP 400 – Method 401
- Accelerated lifetime testing of 2 x 20 years.

## Key Benefits

- Dimensions: Ø x H / 75 X 69 mm
- Weight: 1200 g
- Housing material: Stainless steel / Aluminium
- Communication interfaces: CAN / CANopen
- Service interface: micro USB maintenance flap
- Operating voltage: 15 – 40 Vdc / nominal 24 Vdc
- IP- Rating: IP67
- Sample Temperature: <70 °C , no freezing allowed
- Max sample pressure: 15 bar

PIN	
A	Shield
B	CAN_L+
C	CAN_H+
D	Isolated GND CAN-BUS
E	+24 Vdc
F	GND

